
Model 430

2@4amps, 2@30amps



Mercotac model 430 is ideal for heated roller applications, where connecting to senstive thermocouple signals and simultaneously powering the heater are required.

Model No.	Terminals	Voltage AC/DC	Amp Rating @240VAC	Max. Freq. MHz	Contact Resistance	Max. RPM	Temp Max. F (C) / Min. F (C)	Rotation Torque (gm- cm)	Circuit Separation
430	4	0-250	2@4/2@30	100	<1mΩ	1200	140 (60) /-20(-29)	400	>25M Ω
430-SS	4	0-250	2@4/2@30	100	<1mΩ	1200	140 (60) /-20(-29)	400	>25M Ω

[&]quot;SS" designator indicates stainless steel ball bearing (recommended for wet or corrosive environments)



✓ Model 430 Accessories



50431 Plug Assembly 12 in. wires 14 AWG & 18 AWG Suitable for up to 20 Amps



57430 Boot Kit for dust or splash protection IP51



5030-T Plug Terminal Crimping Tool For Use With 50430 Kit



50430 Plug Kit - No wires, terminals for wire gauges 20 - 16 AWG & 16 - 14 AWG Suitable for up to 20 Amps Also order 5030-T



55251 Terminal 16 - 14 AWG (qty. 2 included)



55250 16 - 14 AWG (qty. 2 included)



22 - 18 AWG (qty. 4 included)

Terminals for other wire gauges available. (22-18 AWG and 12-10 AWG)







✓ Model 430 Suggested Mounting Methods

Model 430 is typically mounted by either the black body or the white plastic bushing on either end using a set screw. When mounting horizontally, mount the Mercotac so the body of the connector rotates.


Typical Body Mount Hole Dimensions


MODEL	HOLE DIAMETER (Ø) *	DEPTH					
430, et al	1.248" (31.70)	.80" (20)					
	Typical Bushing Mount Hole Dimensions						
430, et al	.625" (15.88)	.40" (10)					
With Plug Connector	.625" (15.88)	1.40" (36)					
*Inch (mm) Tolerance Ø	+.001" (+.025) 000" (000)						







Horizontal mount to bushing (not preferred) (May be used if shaft cannot be fitted to body diameter).






Top mount to body.







Floating torque arm mount.



Protective housing mount (Recommended for wash-down or dirty environments. Also recommended for food processing applications).



Vibration isolating mount with flexible bellows.



Installation Notes:

- the up arrow should not point below horizontal
- do not solder to or bend connector tabs
- avoid lateral forces and mechanical loads (overly stiff or tight wires)
- do not rigid mount both ends of connector
- limit mounting eccentricity (runout / wobble) to .005" (.13mm)
- provide overload protection within the circuit
- avoid vibration and bumping motions